




Guide





Back Arrow:
Press when watching TV to go back to Home Screen.

Home:
Returns you to the Roku Home Screen

Arrow Up:
Move through Channels

Arrow Down:
Move through Channels

Refresh:
Reload/Refresh Channel

Rewind:
Page Up in Guide & Rewinds DVR Recordings

OK:
Confirms Selections in Guide or Options Screen

Asterisk Star:
Launches Roku Options if on Home Screen. In BeamStream App, shows options available for the app.

Fast Forward:
Page Down in Guide & Fast Forwards DVR Recordings



Roku® Remote User Guide



Web Portal Instructions

1. Go to beam.fibernet-tv.com
2. Login with your credentials given to you by CTV Beam. The Device Name is what you will call this login. We recommend "Computer."
3. Once logged in, you can scroll the guide, click the expand option on the video to see full screen, or manage your devices.

To Manage Devices:

1. Click the "hamburger" at the top right of the screen. This is the button with 3 bars horizontally.
2. Click "My Devices"
3. From here you can remove devices including the one you are logged in as so that other devices can be used.